

LIRE CE DOCUMENT ATTENTIVEMENT AVANT D'INSTALLER LE LUMINAIRE
ATTENTION: COUPER L'ALIMENTATION ÉLECTRIQUE AVANT D'OUVRIR LE LUMINAIRE
READ THESE INSTRUCTIONS CAREFULLY BEFORE INSTALLING THIS FIXTURE
CAUTION: THE ELECTRICAL POWER MUST BE DISCONNECTED BEFORE OPENING THE FIXTURE

WARNING


THIS PRODUCT MUST BE INSTALLED IN ACCORDANCE WITH THE APPLICABLE INSTALLATION CODE BY A PERSON FAMILIAR WITH THE CONSTRUCTION AND OPERATION OF THE PRODUCT AND THE HAZARDS INVOLVED

THE FLEXIBLE CORD SHALL BE CONNECTED TO AN OUTLET BOX SUITABLE FOR WET LOCATIONS, WITH A LISTED WATERTIGHT CORD GRIP SUITABLE FOR THE SIZE OF CORD AND TRADE SIZE OPENING OF JUNCTION BOX. SUPPLIED BY OTHERS.


AVERTISSEMENT CE PRODUIT DOIT ÊTRE INSTALLÉ SELON LE CODE D'INSTALLATION PERTINENT, PAR UNE PERSONNE QUI CONNAÎT BIEN LE PRODUIT ET SON FONCTIONNEMENT AINSI QUE LES RISQUES INHÉRENTS

LE CORDON FLEXIBLE DOIT ÊTRE CONNECTÉ À UNE BOÎTE DE JONCTION POUR EMPLACEMENTS MOUILLÉS, AVEC UN SERRE-CÂBLE HOMOLOGUÉ ÉTANCHE À L'EAU ET COMPATIBLE À L'OUVERTURE STANDARD DE LA BOÎTE DE JONCTION. FOURNIS PAR D'AUTRES.

**POUR INSTALLATION MURAL AVEC BOÎTE DE JONCTION SOUS LA BASE/
FOR WALL INSTALLATION WITH JUNCTION BOX BELOW THE BASE**



NE PAS RETIRER OU MODIFIER LE CÂBLE D'ALIMENTATION
DO NOT REMOVE OR ALTER THE POWER SUPPLY CABLE



1. EFFECTUER LES BRANCHEMENTS ÉLECTRIQUES
2. DESSERRER LES VIS PRESSION
3. AJUSTER L'ORIENTATION DU LUMINAIRE
4. VISSER LES VIS PRESSION À 75 lbs.in.

1. CONNECT ELECTRICAL CIRCUIT
2. LOOSEN SET SCREWS
3. ORIENT THE FIXTURE
4. TIGHTEN THE SETSCREWS AT 75 lbs.in.

DESIGNER: JS	DATE: 09-17-13	TITRE/TITLE: AS1 LUM ULFW100 LED MEC AL LEDGINE
VÉRIF./INSPEC.:	DATE:	FEUILLE/ SHEET: 1 DE 1
		NO DESSIN/ DRAWING #: 5013252101

PHILIPS
LUMEC