

Fugato 254-264

Installation instructions

Instructions de montage
Montageanleitung
Montage instructie

Instrucciones de montaje
Instruções de montagem
Monteringsinstruktioner
Monteringsvejledning

Kokoonpano- ja kiinnitysohjeet
Montaj yönergeleri
Instrukcja montażu
Οδηγί ες συναρμολογί ης


Szerelési utasítások
Návod k montáži
Návod k montáži
ИНСТРУКЦИЯ ПО МОНТАЖУ






EN
60598

IP20

960°C



				A	B	C	D	
Mini	MBS254	CDM-TC/TCF/TCW G8.5	35W 50W 70W	126	144	140	180	X
		CDM-TC Light boost EBR G8.5	70W					X
		CDM-R20 E27 5kV	35W			158		
	QBS254	HAL-P20 E27	50W					
						140		X
Compact	MBS264	HAL-C GY6.35	75W	175	193		260	
		CDM-T/TF/TW/EBR G12	35 50 70 100 150W			188.5		X
		SDW-T PG12	35 70 100W			203		
		SDW-TG GX12	50 100W			188.5		
		CDM-R30 E27 5kV	35 70W			203		
	QBS264	CDM-R111 GX8.5	35W			188.5		
		HAL-P30S E27	75W			203		
		LBS264 HAL-R111 G53	100W			188.5		



441134064313

Version Date: 05/07/2012

Data subject to change without notice



Printed in France

www.philips.com/lighting

PHILIPS


Installation

1a




« Peut seulement être installé en dehors du volume d'accessibilité au toucher »
 "Only to be installed outside arms reach"


1b









1c



1d



1e



ZBS260 GST


Female =

ZBS260 C2W3


Male Female

ZBS260 W3T

Male Female












F - Le luminaire ne doit être utilisé que complet avec son écran de protection.
 UK- The luminaire shall only be used complete with its protective shield.
 D - Die Leuchte darf nur mit ihren vollständigen Schutzabdeckungen betrieben werden.
 NL - De armatuur mag alleen met beschermplaat gebruikt worden.
 I - L'apparechio deve essere esclusivamente utilizzato con i relativi schermi protettivi.
 S - Armaturen får endast användas tillsammans med dess skyddglas.
 FL - Valaisin saa ainoastaan käyttää suojalasinsa kanssa.
 PL - Do oprawy musi być zamontowany klosz ochronny.
 P - Esta luminária apenas deve ser utilizada completa com o seu escudo de protecção.






SDWT Version




Removal

2a



2b



2c

