## READ AND UNDERSTAND THESE INSTRUCTIONS BEFORE INSTALLING FIXTURE

This fixture is intended for installation in accordance with the National Code and local regulations. To assure full compliance with local codes and regulations, check with your local electrical inspector before installation. To prevent electrical shock, turn off electricity at fuse box before proceeding.

Retain these instructions for maintenance reference.

## INSTRUCTION SHEET NO.

SH23430

Housing

Page 1 of 1

## INSTALLATION INSTRUCTIONS FOR SV5 LENS ACCESSORY





FIGURE 1



- 1. Remove Ballast Cover (Figure 1) and discard.
- 2. Attach <u>Reflector to Housing</u> and secure with 2 screws (see kit bag) (Figure 2).






FIGURE 3

3. Insert <u>Lens</u> in <u>Reflector</u> ( **Figure 3**). Follow steps 1 through 4.

STEP 1

4. To remove <u>Lens</u> insert a flat head screw driver in <u>Slots</u> and twist screw driver to release the Lens (**Figure 4**)





FINAL ASSEMBLY

**FLUORESCENT** 

Canlyte 525 Education Road, Cornwall K6H 6C7 Tel:(613)938-6221 Fax:(613)938-0961 www.canlyte.com

Rev.00 Apr/07