

Philips T5 Essential Batten
TCH085
User Manual

Caution:

- Please read this manual carefully before using the product.
- Please keep the manual for reference later.
- The manufacturer will not be held responsible for improper usage or modifications of the product.
- This product is for individual use only. Linkable connection is not allowed.
- Please keep a space of at least 0.5m between lamp source and any combustible object.

Operation Instruction:

- Do not use the product in outdoor environments.
- The product is suitable for ceiling, wall & suspension mounting.
- Do not use in supply voltage exceeding 220-240V±10% for extended periods.
- Do not touch the lamp when the power is switched on or few minutes after switching off.
- Do not place readily flammable material near the lamp.
- In case of operation failure, please switch off the power and contact your nearest Philips dealer.

Attention:


1. Shut off power supply before replacing lamps or maintenance!
2. This unit is to be installed by qualified electrician only.

Specification

Type	Voltage/Frequency	Power Factor	Color Temp	Nominated Life Time(h)	Dimension(mm)	Mounting distance(L)
14W	220-240V~/50/60Hz	0.6	6500K/4000K/3000K	8000	585x25x37.2	240-400
28W	220-240V~/50/60Hz	0.6	6500K/4000K/3000K	8000	1185x25x37.2	300-700

Electrical insulation classification: I

Batten installation



Lamp replacement

- * **Please shut off and disconnect power before lamp replacement.**
- * **PHILIPS T5 essential lamp is highly recommended to ensure optimal system performance.**

