


Installation Instructions

ID 7408 Sync Wall LED

Standalone or continuous run configurations








TOOLS REQUIRED: Stubby Phillips screwdriver, 3/8 " nut driver.

Module Lengths


Sync wall mount systems come in 4ft and 8ft modules. Overall module lengths are shown to the right. Module lengths do not include endcaps.



Indicates overall length of fixture (excluding endcaps)

Endcaps

Add two endcaps to the overall length of each row.



Mount Spacing

- \cdot Mounts variable within 2" 5" of end or joint. On 8ft module, additional mount to be located within 2" - 5" of center of module.
- · Maximum distance between mounts is 48". Note: Fixture is flush with wall.

Row Configurations

The tables below indicate how 4ft and 8ft modules can be combined to create continuous rows of various lengths.

Nominal row length	4ft module	8ft module
4'	1x	
8'		1x
12'	1x	1x
16'		2x
20'	1x	2x
24'		3x
28′	1x	3x
32'		4x

Installation Instructions


ID_7408_Sync_Wall_LED

Standalone or continuous run configurations




IMPORTANT: Read all instructions at least once prior to beginning installation.

All mount brackets must be secured to wall structure (eg. studs or cross-braces).



Determine power feed location and install 2"x4" utility box (supplied by others) parallel with fixture. Complete connections at utility box with supplied power cord. Attach cover bracket using supplied hardware. Punch power access hole in supplied cover, feed power cord through and attach strain relief on wall side. Attach cover using supplied painted hardware.

NOTE: Bottom of utility box should be in line with bottom of wall brackets.



should be in line with bottom of wall brackets.


Determine fixture mounting location and secure wall brackets to structure using appropriate fasteners (two per bracket, supplied by others). 4ft fixtures: Require two bracket assemblies; 8ft fixtures: Require three bracket assemblies. Brackets must be installed a maximum of 5" from end of fixture (on 8ft fixture, the third bracket can be 5" of ether side of inrow crossplate).

NOTE: Mounted fixture(s) will sit approximately 1/4" above top edge of bracket assembly.


Unpack / Prepare fixtures

Arrange boxed fixtures on floor in specified locations; remove fixtures from boxes; remove plastic from fixtures. Cap all unnecessary power feed holes at back of fixture(s) using supplied 1/2" plugs.


4 Remove Top Reflector



Shift top reflector to the left and then remove the reflector.




Remove the screws holding the front reflector and then remove the front reflector.



With 2 people, raise fixture into position and engage it on hooks located on top of wall brackets, then rotate it down into position. Secure bracket using supplied hardware.

POWER LOCATIONS: Prior to engaging fixture in mounting brackets, feed installed power cord through the access hole at back of the fixture.



To access wiring, remove screw from top pan and lift pan off. Apply strain relief to power cord.

NOTE: Care should be taken when lifting up top reflector to avoid disconnecting internal wiring.

ATTENTION: Install in accordance with national and local building and electrical codes.

Page 2


Installation Instructions

ID 7408 Sync Wall LED

Standalone or continuous run configurations




Complete electrical connections



Complete electrical connections using wire nuts (supplied by others). Re-install pan and hardware removed in STEP 6.


Level and secure first fixture



LEVEL: Using 5/16" hex nut driver, level fixture by adjusting the tilt screw.


SECURE: Secure fixture to wall bracket assemblies by tightening the lock screw.

Install and join additional fixtures to create row



With two people, raise second fixture and engage on mounting brackets (see STEP 4). At joint, remember to insert black gasket.

Complete electrical connections at joints




Complete in-row electrical connections.

NON-POWER LOCATIONS: Use supplied quick-wire connectors. Tuck wires into wire cavity.

POWER LOCATIONS: Remove installed quick-wire connectors and complete electrical connections using wire nuts (supplied by others). Tuck wires into wiring cavity.

NOTE: Use smallest appropriate wire nuts.


Level and secure additional fixture



Level second fixture by adjusting the tilt screw (see step 8). Slide second fixture flush against first fixture and secure joint using supplied nut and bolt hardware (requires 3/8" nut drivers). Secure fixture to wall brackets by tightening the lock screw at each bracket location (see step 8).

Repeat steps 8-10 for each additional fixture(s) in row.


Install Endcaps



Attach endcap to first and last module in each row using supplied hardware.


IMPORTANT: Do not over-tighten endcap fasteners. Ledalite recommends tightening fasteners by hand. When nut is flush with crossplate, turn an additional 1/4 turn.

Re-install Front Reflector



Re-install front reflector using short (stubby) screwdriver.

Install Light Guide and Re-install Top Reflector



Identify smooth side of the Light Guide and ensure it is installed smooth side DOWN.

Install Light Guide panel into LED fixture after joining and wiring is complete. Ensure panel is seated correctly as shown above.

Final Step: Install the top reflector and shift into place.

ATTENTION: Install in accordance with national and local building and electrical codes.

Page 3