

## INSTALLATION DU DÉFLECTEUR CÔTÉ MAISON HOUSE SIDE SHIELD INSTALLATION

ATTENTION: COUPER L'ALIMENTATION ÉLECTRIQUE AVANT D'OUVRIR LE LUMINAIRE  
CAUTION: THE ELECTRICAL POWER MUST BE DISCONNECTED BEFORE OPENING THE FIXTURE

### To install the shield

Remove the optical support from the luminaire by removing the two screws #1.

Remove the sheet metal by removing the screw #2.

To install the shield #3, hook the shield to one edge of the optical plate.

Attach the other end of the shield to the optical plate, you should feel a click.


### Pour installer le déflecteur

Retirez le système optique du luminaire en retirant les deux vis #1.

Retirez la tôle cache-fils en enlevant la vis #2.

Pour installer le déflecteur #3, accrochez le déflecteur côté maison à un bord de la plaque optique.

Attachez l'autre bout du déflecteur à la plaque optique, un déclic doit être ressenti.



DESIGNER: TLD	DATE: 02-11-16	TITRE/TITLE: AS1 OPT 2 LEN 48X LED 4K LEDGINE 3.1
VÉRIF./INSPEC.:	DATE:	FEUILLE/ SHEET: 1 DE 1 NO DESSIN/ DRAWING #: 5013194401

**PHILIPS**  
**LUMEC**