

Low Pressure Sodium Lamps - SOX

Warnings, Cautions and Operating Instructions

WARNING: These lamps must be operated in fixtures designed for use with Low Pressure Sodium lamps. The fixture wattage rating must match the wattage indicated on the outer glass bulb. Do not scratch the outer bulb or subject it to pressure as this could cause the outer bulb to crack or shatter.

Operating the lamp improperly and not following operating instructions may result in **PERSONAL INJURY, PROPERTY DAMAGE, BURNS AND FIRE.**

- 1- If the outer glass bulb is broken, shut off power immediately and avoid making contact with metal parts to prevent electrical shock. Remove the lamp after it has cooled.
- 2-The lamps must be stored and transported in the original packing.
- 3-Be sure power supply is off before installing or removing lamp.
- 4- Use only auxiliary equipment meeting Philips and/or ANSI standards. Use within voltage limits recommended by ballast manufacturer.
- 5- Replace the lamp if the outer glass bulb has been scratched, cracked or damaged in any way.
- 6-Take care in handling and disposing of lamps. If arc tube is broken, avoid skin contact with any of the contents or fragments.
- 7-The arc tube of this lamp contains sodium and mercury. Sodium can generate a high degree of heat, which may cause a fire, when exposed to small amounts of water. Refer to Material Safety Data Sheet on www.philips.com?? Broken lamps may constitute an ignitable and/or reactive hazardous waste. Dispose of in accordance with federal, state and local requirements. Consult with a Federal or State licensed facility, or www.lamprecycle.org for more guidance.