

## INSTALLATION INSTRUCTIONS FOR A HORIZONTAL LAMPS OPEN REFLECTOR IN A CALCULITE PREWIRED RECESSED COMPACT FLUORESCENT MOUNTING FRAME.

**ATTENTION:** Read and understand these instructions before installing fixture. To prevent electrical shock, turn off electricity at fuse box before proceeding.

**Retain these instructions for maintenance reference.**

**CAUTION:** Do not install the fixture on a branch circuit that has a "Ground Fault Circuit Interrupter" (GFCI). Electronic ballasts may cause GFCI tripping.

**Turn off electricity before installation or relamping to restore ballast.**

### A. PREPARATION: (If applicable)

1. Remove the louver from the reflector by pulling it downward. (Fig.1)

### B. TRIM RING:

Note-1: Model with integral border, not applicable. (Fig.2)

Note-2: Model with flush border, do not install with the trim ring. (Fig.3)

Note-3: Model with trim ring. (Fig.5,6)

1. Slide the trim ring over the reflector. (Fig.4,5,6)

### C. SOCKET CUP:

1. Line up the studs with the holes in the reflector. (Fig.7)
2. Fasten in place with the wing nuts. (Fig.7)

### D. REFLECTOR:

#### Frame:

1. Insert the socket cup opposite to the junction box. (Fig.9)
2. Push the reflector up and turn it clockwise. (Fig.10)  
*Note:* To remove, turn the reflector counterclockwise while pulling downward.

#### Cylinder:

1. Connect the reflector connector to the ballast plug, install the reflector and tighten the wing screw. (Fig.8)

### E. LAMP:

1. Line up the lamp pins with the socket and rotate. (Fig.11,12)
2. Push the lamp all the way in.

### F. LOUVER: (If applicable)

1. Align the louver springs with the reflector slots. (Fig.13,14,15)
2. Carefully, push the louver straight up. (Fig.13)

