

INSTALLATION INSTRUCTIONS

DESIGNER FLOOD LUMINAIRE DF5/7/12

Philips Lighting North America
Corporation
200 Franklin Square Drive,
Somerset, NJ 08873, USA

Philips Lighting Canada Ltd.
281 Hillmount Road,
Markham ON, Canada L6C 2S3



IMPORTANT: READ ALL INSTRUCTIONS BEFORE PERFORMING ANY WORK.
BE SURE ALL POWER IS OFF PRIOR TO INSTALLING LUMINAIRES.

WARNING: FIXTURE MUST BE GROUNDED IN ACCORDANCE WITH
APPROPRIATE CODES. FAILURE TO DO SO MAY RESULT
IN SERIOUS INJURY.

FIXTURE IS APPROVED FOR ABOVE GRADE INSTALLATIONS ONLY

STANCHION SURFACE MOUNT

1. SECURE STANCHION POST TO (4) 5/16" STUDS BY OTHERS USING LOCKWASHERS AND NUTS PROVIDED.
2. RUN WIRES FROM CONDUIT TO 1/2" NPT USING A WEATHER TIGHT FITTING. PULL WIRES THROUGH STANCHION POST SO THAT A MINIMUM OF SEVEN INCHES OF WIRE EXTEND BEYOND THE TOP OF THE POST. NOTE: IF EXTERIOR CONDUIT IS NOT USED, WIRES MUST BE PULLED THROUGH STANCHION POST BEFORE IT IS SECURED TO THE (4) 5/16" STUDS.
3. ATTACH TENON ADAPTOR TO FIXTURE/SWIVEL ASSEMBLY BY REMOVING THE SPLICE COVER AND CLAMP FROM THE SWIVEL ASSEMBLY. INSERT TENON ADAPTOR INTO SWIVEL ASSEMBLY AND REINSTALL CLAMP BY SECURELY TIGHTENING THE (2) 1/4-20 BOLTS.
4. ATTACH FIXTURE ASSEMBLY TO POST BY FIRST RUNNING WIRES THROUGH MIDDLE OF TENON. ROUTE FIXTURE AND SUPPLY WIRES THROUGH CLAMP AS SHOWN. INSTALL TENON ADAPTOR GASKET. SLIDE TENON INTO POST MAKING SURE TO ALIGN THE (2) MOUNTING HOLES. SECURE TENON ADAPTOR WITH (2) FLAT HEAD SCREWS.
5. MAKE ELECTRICAL CONNECTIONS. FIXTURE LINE TO SUPPLY LINE, COMMON TO COMMON, AND GROUND TO GROUND. PLACE EXCESS WIRES AND SPLICES IN THE SPLICE COMPARTMENT.



6. UNSCREW THE TWO BOLTS IN THE UPPER CORNERS OF THE LENS FRAME. OPEN FRAME, INSTALL LAMP, CLOSE AND SECURE FRAME BEING CAREFUL NOT TO OVER TIGHTEN THE BOLTS.

7. THE FIXTURE MAY BE AIMED ON THE VERTICAL AXIS BY LOOSENING THE CLAMP BOLTS AND ROTATING THE FIXTURE AS REQUIRED. TO AIM ON THE HORIZONTAL AXIS, LOOSEN THE BOLT IN THE CENTER OF THE SWIVEL MOUNTING COVER. EACH MARK ON THE MOUNTING COVER INDICATES 15°. THE INTERNAL TEETH LOCK EVERY 5°. TIGHTEN BOLTS WHEN AIMING IS COMPLETE.

8. SECURE SPLICE COVER TO CLAMP WITH SCREW PREVIOUSLY REMOVED.